
MIC
IN
OUT
Hp
K20-JTAG
Display
50M JTAG
BOOT
USR1
USR2
SPI
RST
ETH1
ETH0
RS232
CAN
K20-USB
USB
3V3 On/Off
5V-Alt.
5V-IN
Front
BUCHSE
no TH Parts