

# BSP Yocto FSL iMX7 PD18.1.0 Release Notes

Operating System	Linux
BSP Release Status	RELEASED
Release Date	09 Feb 2018
Repository	<a href="#">PHYTEC Public Repos</a>
Binaries	<a href="#">BSP-Yocto-FSL-iMX7-PD18.1.0</a>
Source Archive	
Release Notes	<a href="#">Click Here</a>

## Introduction

This BSP provides a basis for development, deployment and execution of Linux based applications on the iMX7 System on Module (SOM). For detailed information on the various software components included in the release and how to use them, please refer to the [Quickstart](#).

- [Introduction](#)
- [Versioning](#)
  - [Software](#)
    - [Yocto Machine Configuration Table](#)
    - [Linux Device Tree Summary](#)
  - [Compatible Hardware](#)
    - [Supported Hardware Versions](#)
  - [Compatible Expansion Boards and Accessories](#)
- [BSP Download](#)
- [Quickstart](#)
- [BSP Features](#)
- [New In This Release](#)
- [Fixed In This Release](#)
- [Not Tested](#)
- [Known Issues](#)
  - [PHYTEC Known Issues](#)
  - [NXP Known Issues](#)
- [Technical Support](#)

## Versioning

### Software

Linux Kernel	4.9.11 (Based on NXP Release <a href="#">L4.9.11_1.0.0_ga</a> )
U-Boot	2017.03 (Based on NXP Release <a href="#">L4.9.11_1.0.0_ga</a> )
Yocto	2.2 Morty (Based on NXP Release <a href="#">L4.9.11_1.0.0_ga</a> )
Qt	Not Supported (Click <a href="#">here</a> for more info)
Host OS	Tested on 64-bit Ubuntu 16.04 LTS

### Yocto Machine Configuration Table

This BSP release supports various configurations of the phyBOARD-Zeta i.MX7. **You will need to know which Yocto machine configuration corresponds to your kit in order to build the appropriate BSP.** By default, only the standard kit configurations are shown in the table. If you have a different kit, use the filters below to search by Kit Part Number or SOM. The U-Boot defconfig and kernel device tree file names are important when creating custom U-Boot and kernel images outside of Yocto development.

Yocto Machine Config	Kit Part Number	SOM Part Number ( <a href="#">Click here</a> for description)	Modules	U-Boot defconfig	Kernel Device Tree File
<b>imx7d-phyboard-zeta-001</b>	PB-01910-001 (i.MX7Dual Kit)	PCM-061-2110111C	PEB-EVAL-02 PEB-AV-02	mx7d_pcm061_21x_config	imx7d-phyboard-zeta-001.dtb
<b>imx7s-phyboard-zeta-002</b>	PB-01910-002 (i.MX7Solo Kit)	PCM-061-0502100E	PEB-EVAL-02	mx7s_pcm061_05x_config	imx7s-phyboard-zeta-002.dtb

## Linux Device Tree Summary



The following is an example describing the structure of the device tree for the standard phyBOARD-Zeta Kit (machine configuration imx7d-phyboard-zeta-001).

Please look at the dts file corresponding to your machine configuration for the included dtsi files.

Hardware Target	Device Tree File Descriptions	Filename
<b>i.MX7D phyBOARD-Zeta (PB-01910-001)</b>	<b>Default dts build target</b>	<b>imx7d-phyboard-zeta-001.dts</b>
	Processor	imx7d.dtsi (includes imx7s.dtsi)
	SOM ( <i>Superset</i> ) - enables all SOM features.	imx7-phycore-som.dtsi
	SOM Variant- excludes features that are not supported by the BOM population options for PCM-061-2110111C.	imx7d-pcm-061-2110111c.dtsi
	Carrier Board	imx7d-pba-c-09.dtsi (includes imx7s-pba-c-09.dtsi)
	LCD Display Adapter	imx7-peb-av-02.dtsi
	Evaluation Board	imx7-peb-eval-02.dtsi
	WiFi/Bluetooth Module	imx7-peb-wlbt-03.dtsi

Alternate dts **imx7d-phyboard-zeta-001-m4.dtb**: configure u-boot to use this DTS if running Linux on the Cortex-A7 while running FreeRTOS on the Cortex-M4

## Compatible Hardware

### Supported Hardware Versions

Hardware Description	Part Number	Configuration Details (i.MX7 / DDR3 / eMMC or NAND / Ethernet PHY populated)	PCB Version
phyCORE-i.MX7 SOM	PCM-061-2110111C.A1	Dual / 1GB / 4GB eMMC / Yes	1458.2
	PCM-061-2110111C.A0		
	PCM-061-0502100E.A0	Solo / 256MB / 256MB NAND / No	
	PCM-061-2111101E.A0	Dual / 1GB / 4GB eMMC / No	
	PCM-061-2211101E.A0	Dual / 1GB / 8GB eMMC / No	

	PCM-061-211111E.A0	Dual / 1GB / 4GB eMMC / Yes	
phyBOARD-Zeta Carrier Board	PBA-C-09.A4		1459.2
	PBA-C-09.A5		1459.3



Device tree changes are required to support earlier SOM and Carrier Board revisions. Visit the [PHYTEC Support Portal](#) to open a support ticket for help on how to make the device tree changes.

## Compatible Expansion Boards and Accessories

Module Name	Part Number	PCB Version	Description
<a href="#">LCD Display Adapter with 7" capacitive display</a>	PEB-AV-02-070W.A0 (Includes AV module, display, and cable)	1415.1	ETM0700G0DH6 LCD Display/ Capacitive touch interface
<a href="#">Evaluation Board</a>	PEB-EVAL-02	1460.0	Connects to expansion header and provides: UART1, UART2, JTAG, I2C EEPROM, three user buttons, three user LEDs
<a href="#">WiFi/Bluetooth Module</a>	PEB-WLBT-03-CA.A1	1478.1	LAIRD Sterling-LWB module, connects to phyBOARD expansion header

## BSP Download

Prebuilt images of BSP-Yocto-FSL-iMX7-PD18.1.0 can be downloaded and extracted from the link below:

[BSP-Yocto-FSL-iMX7-PD18.1.0](#)

## Quickstart

Quickstarts for BSP-Yocto-FSL-iMX7-PD18.1.0:

[BSP Yocto FSL i.MX7 PD18.1.0 Quickstart](#)

## BSP Features

The following table lists the interfaces available from the phyCORE-iMX7 SOM.

- **Implemented** - driver support exists in the kernel.
- **Tested** - the interface has been configured in the device tree and was tested by PHYTEC
- **Status in Device Tree** - the corresponding device tree nodes are enabled in the device tree. See [Linux Device Tree Summary](#) for more information.



The "Status in Device Tree" column is specifically for the standard phyBOARD-Zeta kit (machine configuration imx7d-phyboard-zeta-001).

Please look at the dts file corresponding to your machine configuration for differences.

Interface	Detail	Implemented	Tested	Status in Device Tree	Notes
UART	uart1	Yes	Yes	Okay	DB9 connector on <a href="#">PEB-EVAL-02</a>
	uart2	Yes	Yes	Disabled	DB9 connector on <a href="#">PEB-EVAL-02</a>  Disabled for use as serial console on Cortex-M4 FreeRTOS
	uart3	Yes	No	Disabled <sup>1</sup>	expansion header
	uart4	Yes	No	Disabled <sup>1</sup>	
	uart5	Yes	Yes	Okay	RS232 default serial console at Connector X2

	uart6	Yes	No	Disabled <sup>1</sup>	expansion header
	uart7	Yes	Yes	Okay	expansion header - Configured for BT on PEB-WLBT-03
I2C	i2c1	Yes	Yes	Okay	expansion header
	i2c2	Yes	Yes	Okay	AV Connector X4
	i2c3	Yes	No	Disabled <sup>1</sup>	
	i2c4	Yes	Yes	Okay	expansion header
Ethernet	RGMII1	Yes	Yes	Okay	KSZ9031RNX PHY on SOM, Connector X8
	RGMII2	Yes	Yes	Okay	KSZ9031RNX PHY on CarrierBoard, Connector X7
SAI	sai1	Yes	No	Disabled <sup>1</sup>	Audio/Video Connector X4
	sai2	Yes	No	Disabled <sup>1</sup>	expansion header
	sai3	Yes	No	Disabled <sup>1</sup>	
MMC/SDIO	SD1	Yes	Yes	Yes	microSD slot connector X11
	SD2	Yes	No	Disabled <sup>1</sup>	expansion header
	SD3	Yes	Yes	Okay	signals routed to eMMC.
Communication	MultiCore Communication with Cortex-M4 (RPMsg)	Yes	Yes	Okay	See <a href="#">FreeRTOS release</a> for more info.
	<a href="#">Laird Sterling LWB Bluetooth</a>	Yes	No	Disabled	on PEB-WLBT-03. See <a href="#">Not Tested</a> section for details
	<a href="#">Laird Sterling LWB WiFi</a>	Yes	No	Disabled	on PEB-WLBT-03. See <a href="#">Not Tested</a> section for details
USB	usb1	Yes	Yes	Okay	USB-A Host Connector X9
	usb2	Yes	Yes	Okay	USB-AB OTG Connector X10
	usbh (HSIC)	Yes	Yes	Disabled	expansion header
CAN	can1	Yes	Yes	Okay	Header X1
	can2	Yes	No	Disabled <sup>1</sup>	
SPI	spi1	Yes	No	Disabled <sup>1</sup>	expansion header
	spi2	Yes	No	Disabled <sup>1</sup>	expansion header
	spi3	Yes	No	Disabled <sup>1</sup>	expansion header
	spi4	Yes	No	Disabled <sup>1</sup>	
ADC	adc1	Yes	Yes	Okay	expansion header
Display and Touch	LCD Display	Yes	Yes	Okay	via expansion board <a href="#">PEB-AV-02</a>
	Analog LCD Touch	Yes	Yes	Okay	Capacitive ETM-FT5x06 via expansion board <a href="#">PEB-AV-02</a>
	Backlight	Yes	Yes	Okay	PWM via pwm4 via expansion board <a href="#">PEB-AV-02</a>
GPIO	User Buttons and LEDs	Yes	Yes	Okay	User LED GPIO2_10 on CarrierBoard  Three user LEDs and three buttons on <a href="#">PEB-EVAL-02</a>
Memory	8/16-bit NAND Flash (GPMC)	Yes	Yes	Disabled	MT29F4G08 - not populated in default SOM configuration
	SPI NOR Flash	Yes	Yes	Okay	N25Q128A on QSPI_A
	EEPROM on SOM	Yes	Yes	Okay	M24C32 on i2c1
	EEPROM on eval board	Yes	Yes	Okay	CAT24C32 on i2c4 <a href="#">PEB-EVAL-02</a>
	eMMC	Yes	Yes	Okay	On SD3  PCM-061.A0 -.A4 SOMs: MTFC4GMDEA-4M  PCM-061-2110111C.A1: MTFC4GACAJCN-4M IT

RTC	Internal i.MX7	Yes	Yes	Okay	SNVS RTC
	External RTC	Yes	Yes	Okay	RV-4162-C7 on I2C1
Power Management	PMIC	Yes	Yes	Okay	PF3000 on I2C1
JTAG	JTAG				ARM JTAG 20 connector on <a href="#">PEB-EVAL-02</a>
PCIe	mini-pcie	Yes	Yes	Okay	connector X12

[1] Interface requires additional configuration, such as pinmuxing. It may be possible to change the software configuration to utilize this interface even if it is not being set in the board's default configuration. Please see [NXP's i.MX7D Technical Reference Manual](#) for more information on the various modes each pin can be muxed to.

## New In This Release

- **Yocto**
  - **Version:** Ported to Yocto version 2.2 Morty
  - **Yocto Image:** supported image name changed from "fsl-image-gui" to "fsl-image-validation-imx".
    - The image type is the same, just the naming has been changed by NXP. Note that the image name "fsl-image-gui" is still functional but simply uses the recipe for fsl-image-validation-imx.
- **Linux**
  - **Version:** Migrated from Linux Kernel v4.1.15 to v4.9.11
  - **Devicetree**
    - **imx7s.dtsi:** Updated DTS structure to use separate processor dtsi for i.MX7 Solo, imx7s.dtsi. The i.MX7 Dual dtsi file, imx7d.dtsi, now includes the imx7s.dtsi and enables additional features.
    - Created separate carrier board dtsi files for i.MX7 Dual and Solo since the Solo does not support certain interfaces that are brought out on the carrier board. The new carrier board dtsi files are named "imx7s-pba-c-09.dtsi" and "imx7d-pba-c-09.dtsi".
- **U-Boot**
  - **Version:** Migrated from v2016.03 to v2017.03
  - **Devicetree:** switched from board file to device tree.

## Fixed In This Release

- **Linux:**
  - imx7s-phyboard-zeta-002: reduce the size of CMA allocated on boot. Due to performance issues with the 4.9 kernel upgrade, less memory has been allocated to CMA so that more is available for the rest of the system.

## Not Tested

- **PEB-WLBT-03:**
  - Driver support for Laird Sterling LWB has not been tested with Linux v4.9.11
- **Booting via network**
- **Qt5** - NXP includes "fsl-image-qt5" Yocto Image in the BSP but it is meant for i.MX SoCs with hardware graphics, and is not supported by NXP or PHYTEC for the i.MX7D.

## Known Issues

### PHYTEC Known Issues

- **Ethernet:**
  - iperf3 is included with the Morty Yocto BSP. With UDP, this command reports much lower bandwidth than expected when compared with iperf command.
- **eMMC:**
  - **Flashing with U-Boot:**
    - fsl-image-validation-imx-imx7d-phyboard-zeta-001.sdcard image is too large to be loaded into memory (1GB) from u-boot.
    - Workaround: Partition and flash eMMC from Linux instead. See [Quickstart](#) for instructions.
  - HS400 warnings/errors: configure eMMC to run at maximum 100MHz as a work around. See commit [b8f6c1b7780](#) for more information.
- **Linux IMX Busfreq driver:**
  - Driver disabled by default due to impaired UART console functionality when the system is idle (Low frequency setpoint).
  - For dynamic bus frequency scaling and improved power consumption, the busfreq driver can be enabled in the device tree by removing the "fsl,freq\_scaling\_disabled" property in imx7-phycore-som.dtsi. It can also be controlled in Linux sysfs:

```
echo 1 > /sys/bus/platform/drivers/imx_busfreq/soc\:busfreq/enable
```

- NAND:
  - 256MB NAND is too small to flash fsl-image-validation-imx filesystem. Booting from NAND was tested with core-image-minimal Yocto image, which is included with release binaries.

## NXP Known Issues

See i.MX Linux Release Notes from NXP in [L4.9.11\\_1.0.0 BSP Documentation](#)

## Technical Support

---

For further information or to report any problems, visit the [PHYTEC Support Portal](#)